Philips
Remote control

CRP614

Controls your device remotely

Fast and easy control of your device by pressing the buttons.

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS

sense and simplicity

Specifications

Replaceable part

- Fits product types:: 14PT1345/58, 14PT2665/00, 14PT2665/01, 14PT2665/05, 14PT2665/58, 21PT1354/48, 21PT1354/58C, 21PT1654/48, 21PT1654/58C, 21PT1664/05S, 21PT1664/58, 21PT1664/58C, 21PT1664/58S, 21PT1865/58, 21PT2264/20, 21PT2664/20, 21PT2665/01, 21PT2665/58, 21PT2665/58C, 21PT2684/21, 21PT2684/48, 21PT4255/00, 21PT4425/58, 21PT4425/58C, 21PT4475/48, 21PT4475/58, 21PT4475/58C, 21PT5305/58, 21PT5505/58, 21PT5505/58S, 25PT4455/20, 25PT4475/48, 25PT5025/58, 25PT5105/58, 25PT5305/58, 28PT4404/58, 28PT4455/20, 28PT5025/58, 28PT5105/58, 29PT5305/58, 72TA5215/00

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.

Issue date 2011-10-24

Version: 1.0.1

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com